
Octaback, octashock!

Posted by tIB - 2013/09/11 04:42

Octatrack is back in the house, yay!

Octatrack appears to be giving me minor electric shocks when plugged into the mains, even when not turned on... Boo!

Anyone have any ideas as to why this could be? It seems to be working fine though if I touch the panel screws when using it I get the unnerving feeling electricity is running through me!

Edit: strangely it seems fine when plugged into a four way plug.

=====

Re:Octaback, octashock!

Posted by darenager - 2013/09/11 05:59

Is it doing it without any audio or midi connected?

=====

Re:Octaback, octashock!

Posted by neilbaldwin - 2013/09/11 07:33

Tried the power supply from your Machinedrum?

=====

Re:Octaback, octashock!

Posted by J C Selector - 2013/09/11 07:46

Sounds like an earth issue maybe, where there is a voltage difference between two earths.
Make sure your using the same power circuit for all gear.

=====

Re:Octaback, octashock!

Posted by twistedspace - 2013/09/11 09:01

I get this on my mdw & mnm if I don't have them plugged into my mixer. I think it's due to the switch mode power supply.

See.....

<http://enclydion.blogspot.co.uk/2012/04/my-laptop-bit-me-shocking-truth.html>

=====

Re:Octaback, octashock!

Posted by tIB - 2013/09/11 14:07

Yeah, is doing it with nothing else connected - I have a spare psu and will try that tonight.

=====

Re:Octaback, octashock!

Posted by darenager - 2013/09/11 17:23

Right then almost certain it is related to the SMPSU, if it works ok in the 4 way lead it is an earthing issue or other problem in the socket where you are getting the shock, it could be a loose earth wire, or it could be that the live and

neutral are reversed somewhere, or it could be another problem.

Try as Neil suggested and use the MD PSU in the same socket where you were getting the shock - and I assume you are talking that kind of tingly shock rather than a zap?

Have a read of the link twistedspace posted it gives a fairly decent explanation. I really am not a fan of these type of PSU for these and other problems, but they are in pretty much everything today.

=====

Re:Octaback, octashock!

Posted by RobbieNerve - 2013/09/11 22:11

tIB wrote:

Octatrack is back in the house, yay!

Octatrack appears to be giving me minor electric shocks when plugged into the mains, even when not turned on... Boo!

Anyone have any ideas as to why this could be? It seems to be working fine though if I touch the panel screws when using it I get the unnerving feeling electricity is running through me!

Edit: strangely it seems fine when plugged into a four way plug.

This is normal.

It's the power of elektron transferring to your body.
Don't fight it, just let it enter your body.

-C-

=====

Re:Octaback, octashock!

Posted by tIB - 2013/09/12 02:27

It's a feature not a bug? :lol:

Cheers for the shouts, I'll try on another psu and see if it's the same. Sounds like it's normal though(?) - definitely tingly rather than hair raising!

=====

Re:Octaback, octashock!

Posted by anselmi - 2013/09/12 02:27

tIB wrote:

Octatrack is back in the house, yay!

Octatrack appears to be giving me minor electric shocks when plugged into the mains, even when not turned on... Boo!

this is just because it knows you got rid of a previous one...octas got a strong union against abandoning owners:P

welcome back to the 4-parts hell Andy!!!:laugh:

=====

Re:Octaback, octashock!

Posted by tIB - 2013/09/12 02:53

Same with other psu.

Octarevenge!

=====

Re:Octaback, octashock!

Posted by jonah - 2013/09/12 11:55

twistedspace wrote:

I get this on my mduw & mnm if I dont have them plugged into my mixer . I think it's due to the switch mode power supply.

See.....

<http://enclydion.blogspot.co.uk/2012/04/my-laptop-bit-me-shocking-truth.html>

Huh, I wonder if this is why the iPad feels like it's vibrating when it's plugged in.

=====