

---

## A4 Performance Mode

Posted by ericg - 2013/09/13 03:54

---

In the performance section, how do you change the track you want to effect, cant seem to do it. I'm talking about the T1 at the top. Default is T1 but want to change this

Thanks

=====

## Re:A4 Performance Mode

Posted by ericg - 2013/09/13 04:08

---

Got it.....just press down once to change tracks

=====