

---

## mono meter question

Posted by dethdeth - 2005/06/18 00:06

---

how do i change the meter or time signature in the MNM, the manual claims to have instructions on page 51, but it isnt there... i imagine the answer is right in front of me!  
thanks

=====

## Re: mono meter question

Posted by glaive - 2005/06/18 01:06

---

Press Function + Scale Setup and you'll get the meter ratio.

=====