i just bought a monomachine, it was working, then while i was trying to syncronize it with logic, i went to multi trig, and i don't know, i was just browsing on it, and now not sound comes out either from the headphones nor from the main master...does anyone know what is going on?

Re:problems Posted by EmTeX - 2010/01/02 02:07

have you turned the volume knob on :-) sounds strange
